



FIREBIRD EVO Cutaway cables setup

Our FIREBIRD EVO comes with the yellow Lolon cutaway cables **uncut**.

To size them correctly, please make sure the risers are attached to the 3-ring system of the EVO prior to cutting.

First cut RSL side: Put tension on the riser and cut cable at height of the apex of the riser safety housing.

Then do the NON RSL side: This cable side will be cut 2.5 cm (1") shorter, below the housing apex line.

